JA-183M Bezdrátový magnetický detektor otevření

Detektor JA-183M je komponentem systému firmy JABLOTRON. Je určen k detekci otevření dveří, oken apod. Detektor komunikuje bezdrátově a je napájen z baterie.

Instalace

Výrobek montuje proškolený technik s platným certifikátem výrobce.

Vyberte vhodné místo pro instalaci. Detektor reaguje na oddálení magnetu. Vysílací část se montuje na pevnou část dveří (okna) a magnet na pohyblivou část. Vyhněte se montáži přímo na kovové předměty (ovlivňují negativně činnost magnetického senzoru i rádiovou komunikaci).

1. Otevřete kryt detektoru (stiskem západky viz obrázek 1).



Obrázek 1 a 2

2. Přišroubujte zadní plast na pevnou část dveří (okna) Značky A, B na tomto plastu vyznačují umístění magnetu (obrázek 3).



Obrázek 3 a 4 - 1. montážní otvory pro upevnění vysílače; 2. montážní otvory pro upevnění magnetu A, 3. pozice magnetu A, B; 4. sériové číslo; 5. jazýčkový kontakt; 6. baterie CR123A; 7. sabotážní snímač; 8. nastavení reakce

3. Přišroubujte magnet na pohyblivou část dveří (okna). Magnet v plastovém pouzdře umístěte středem pouzdra proti šipce A, prstencový magnet musí být proti šipce B. Vzdálenost magnetu od vysílací části má být při zavřených dveřích co nejmenší. Vzdálenost pro aktivaci při oddálení magnetu ve všech osách a pro nemagnetický / magnetický montážní podklad jsou uvedeny v obrázku 5 a 6. *Pozn. Pro výškové nastavení A magnetu použijte dodanou podložku.*



Obrázek 5 a 6

4. Naučte detektor do ústředny (přijímače). Řiďte se návodem k ústředně (přijímači). Učící signál je vyslán ve chvíli připojení baterie. *Pozn. Budete-li detektor do přijímače učit poté, co už měl zapojenou baterii, nejprve ji odpojte, pak stiskněte a uvolněte kontakt krytu (vybije se zbytková energie) a teprve potom proveďte učení.*
5. Nastavte funkce detektoru – viz Nastavení
6. Vysílací část nasaďte na zadní plast a zacvakněte.
7. Vyzkoušejte spolehlivou funkci detektoru.
8. Západku lze zajistit zašroubováním dodaného šroubku (obrázek 2).

Nastavení

Propojka INS / DEL určuje, zda detektor leží v přístupové cestě do domu a poskytuje **odchodové a příchodové zpoždění** = pozice **DEL**. Naopak pozice **INS** znamená **okamžitou reakci** systému. *Pozn. Nastavení má význam pouze při použití s ústřednou Jablotron s nastavenou reakcí NATUR. Je-li v ústředně detektoru nastavena jiná reakce, nebo používáte-li detektor s přijímačem JA-182N nebo JA-180N nemá nastavení přepínače žádný význam.*

Detektor má dva režimy funkce, které jsou indikovány jedním nebo dvěma bliknutími signálky při vložení baterie.

Jedno bliknutí znamená, že detektor systému **hlásí otevření i zavření**. Je tak možné sledovat stav okna nebo dveří. Dvě bliknutí znamenají, že detektor reaguje **pouze při otevření** (oddálení magnetu).

Přepnutí režimu provedete tak, že stisknete a podržíte ochranný spínač krytu, vložíte baterii a spínač uvolníte 3-5 sekund po vložení baterie. Detektor poté blikne jednou nebo dvakrát podle právě zvoleného režimu.

Testování detektoru

Po dobu 15 minut od uzavření krytu indikuje detektor aktivaci signálkou. Ústředna umožňuje v servisním režimu kontrolovat signál detektoru včetně měření jeho kvality.

Výměna baterie v detektoru

Systém kontroluje stav baterie, a pokud se přiblíží její vybití, informuje uživatele (případně i servisního technika) komunikátorem systému. Detektor dále funguje a navíc indikuje každou aktivaci bliknutím signálky. Baterii doporučujeme vyměnit do 2 týdnů. Výměnu baterie provádí technik v servisním režimu. Po výměně baterie otestujte funkci detektoru.

*Pozn. Je-li do detektoru založena **slabá baterie, bude jeho signálka cca 1 min. blikat**. Pak začne detektor fungovat, ale bude hlásit vybitou baterii. Použitou baterii nevhazujte do odpadu, ale odevzdejte do sběrného místa.*

Odebrání detektoru ze systému

Systém hlásí případnou ztrátu detektoru. Pokud jej úmyslně demontujete, musíte jej také vymazat v ústředně.

Technické parametry

Napájení	Lithiová baterie typ CR123A (3,0 V/1,4 Ah)
	Upozornění: Baterie není součástí balení
Typická životnost baterie	cca 3 roky (pro max. 20 aktivací denně)
Komunikační pásmo	868,1 MHz, protokol Jablotron
Komunikační dosah	cca 300 m (přímá viditelnost)
Typická rozpínací/spínací vzdálenost	obrázek 5 a 6
Rozměry	vysílací část 75 x 31 x 23 mm
	magnet A: 56 x 16 x 15 mm, magnet B: Ø10 x 4 mm
Prostředí dle ČSN EN 50131-1	II. vnitřní všeobecné
Rozsah pracovních teplot	-10 °C až +40 °C
Klasifikace	stupeň 2
	dle ČSN EN 50131-1, ČSN EN 50131-2-6, ČSN EN 50131-5-3
Dále splňuje	ČSN ETSI EN 300 220, ČSN EN 50130-4, ČSN EN 55022, ČSN EN 60950-1
Podmínky provozování	ČTÚ VO-R/10/

JABLOTRON ALARMS a.s. prohlašuje, že výrobek JA-183M je navržen a vyroben ve shodě s harmonizačními právními předpisy Evropské unie: směrnice č.: 2014/53/EU, 2014/35/EU, 2014/30/EU, 2011/65/EU, je-li použit dle jeho určení. Originál prohlášení o shodě je na www.jablotron.com v sekci Ke stažení.

Poznámka: Výrobek, ačkoliv neobsahuje žádné škodlivé materiály, nevyhazujte do odpadků, ale předejte na sběrné místo elektronického odpadu. Podrobnější informace na www.jablotron.com v sekci Ke stažení.

JABLOTRON ALARMS a.s.
Pod Skalkou 4567/33 | 46601 | Jablonec n. Nisou
Czech Republic | www.jablotron.com

JA-183M Wireless magnetic door detector

The JA-183M is a component of Jablotron's alarm system. It is designed to detect the opening of doors, windows etc. The battery-powered detector communicates via Jablotron radio protocol.

Installation

Installation shall only be undertaken by technicians holding a certificate issued by an authorized distributor.

Choose the suitable place for detector's installation. The detector reacts to the removal of its magnet unit. The electronics should be installed onto the non-moving part of windows or doors, and the magnet onto the moving part. Avoid locating it directly on a metal frame as metal influences the functioning of the magnetic sensor and radio communication.

1. Open the detector cover by pressing the tab in. (**Fig. 1**)



Fig. 1** and **2

2. Screw the rear cover to the solid part of the door/window. The marks A and B show the right position of the magnet. (**Fig. 3**)



***Fig. 3 and 4** - 1. mounting holes of the detector; 2. mounting holes of the magnet A, 3. magnet A and B position marks; 4. serial number; 5. reed contact; 6. battery CR123A; 7. tamper; 8. settings jumper*

3. Attach the magnet to the moving part of the window. The standard magnet in a plastic housing opposite the A arrow and the whorl shape magnet against the B arrow. Its distance from the detector should be as small as possible when the door/window is closed. In the picture **Fig. 5** and **Fig. 6** are shown the reaction areas for magnets in millimeters in three axes of movement and on the non-magnetic / magnetic surface. **Note:** Use the supplied plastic part to compensate the possible height difference for magnet A.



Fig. 5 and 6

4. Enroll the detector into the control panel (receiver). Check its manual for more info. The enrollment signal is transmited when the battery is inserted. Note: To enroll a detector after having already connected a battery, first disconnect the battery, and press and release the tamper sensor to discharge any remaining charge to get the device ready for enrolment.
5. Set the detector's reaction See settings chapter.
6. Mount the front cover onto the rear part
7. Test the detector's function.
8. The tab can be fixed using supplied screw (**Fig. 2**).

Settings

The **DEL** position of the jumper provides entrance & exit delays for detectors installed in a building entrance. **INS** position allows the detector to instantly trigger alarm activation if the control panel is armed.

Note: This DIP switch (INS/DEL) only has an effect if the detector has a natural reaction assigned to its address in the Jablotron control panel. It also has no effect when used with a JA-182N or JA-180N receiver.

The detector has two different modes. The mode is indicated by one or two short flash when the battery is inserted.

One flash means that it indicates both opening and closing the door or window. The control panel knows the status of doors / windows. Two flashes means the pulse mode in which the detector indicates only opening the door or window.

The mode can be set (changed) when keeping the tamper switch pressed while installing the battery for 3 to 5 seconds.

Testing the detector

15 minutes after closing the detector cover, the LED indicates detector triggering. The strength and quality of detector signals can be measured by the control panel in Service mode.

Battery replacement

The detector monitors its battery voltage and if too low, a report is sent to the control panel to inform the installer or user. The detector continues to function and shows each triggering of the detector with a flash of its LED. Battery replacement should not be delayed by more than two weeks. This should be done by a qualified technician with the control panel in Service mode.

*Note: If a **partly discharged battery is inserted then the LED start flashing for one minute**. Then the detector will work but the Lo Bat signal will be send to the control panel. Expired batteries should not be thrown into the garbage, but disposed of according to local regulations.*

Removing the detector from the system

If a detector is removed, the control panel reports the removal. The detector has to be deleted in the control panel before intentional removal.

Technical parameters

Voltage:	Lithium battery type CR123A (3.0 V/1.4 Ah)
	Please note: Battery is not included
Typ. battery lifetime:	approx. 3 years for max.20 daily activations
Communication band:	868.1 MHz, Jablotron protocol
Communication range:	approx. 300 m (open area)
Typical sensitivity range:	see **Fig. 5** and **Fig. 6**
Dimensions:	transmitter part 75 x 31 x 23 mm
	A magnet: 56 x 16 x 15 mm, B magnet: Ø10 x 4 mm
Operational environment according to EN 50131-1:	
	II. Indoor general
Operational temperature range:	-10 °C to +40 °C
Classification:	grade 2
	according to: EN 50131-1, EN 50131-2-6, EN 50131-5-3
Complies with:	ETSI EN 300 220, EN 50130-4, EN 55022, EN 60950-1
Can be operated according to:	ERC REC 70-03

JABLOTRON ALARMS a.s. hereby declares that the JA-183M is in a compliance with the relevant Union harmonisation legislation: Directives No: 2014/53/EU, 2014/35/EU, 2014/30/EU, 2011/65/EU. The original of the conformity assessment can be found at www.jablotron.com - Section Downloads.

Note: Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please return the product to the dealer or contact your local authority for further details of your nearest designated collection point.

JABLOTRON ALARMS a.s.
Pod Skalkou 4567/33 | 46601 | Jablonec n. Nisou
Czech Republic | www.jablotron.com