# JABLOTRON ALARMS a.s. Pod Skalkou 4567/33 | 46601 | Jablonec n. Nisou Czech Republic | www.jablotron.com

### The JA-187J wireless wrist button

The JA-187J is a component of Jablotron's alarm system. It allows users to trigger panic alarms or to control appliances remotely. It is especially designed for personal calls for help. The battery-powered wireless button communicates via Jablotron radio protocol.

The button can be worn on your wrist like a watch or it can hang around your neck (an appropriate strap is supplied in the package). Caution: When hanging around the neck, the strap must be equipped with a mechanical release which disconnects the strap whenever the loading force exceeds 40N.

### Enrolling to an Jablotron control panel

The button can be used with an Jablotron control panel for triggering panic alarms. Take the following steps to enroll the button:

- Enter enrollment mode on the control panel by keying in "1" in Service mode (the desired device address can be chosen by the arrow keys).
- 2. Hold the button until you see the button's LED flash once.
- 3. The button will enroll to the chosen position.
- 4. Exit enrollment mode by pressing "#".

The control panel's natural reaction to the button is a Panic alarm. A different reaction can be programmed if desired.

The wrist button can be enroled by inserting the battery (step 2).

### **Functionality**

By factory default, the button reacts to pressing with beeps and flashes. This way it is signalled that the time is getting close for alarm triggering. If you re-press the button within 5 seconds, the pre-alarm condition will be cancelled. If no cancellation occurs, an alarm signal will be sent after 5 seconds. This feature allows the user to cancel accidental button pressing.

# The button can be reconfigured to another function as follows:

- Open the button unit (release 4 screws from below) and pull out the electronics.
- 2. Disconnect the battery from the holder (it can be pulled out using a thin tool). Wait for 15 seconds.
- Press and hold the button with one hand and insert the battery with your other hand. Keep the button pressed until beeps are heard (after 2 seconds approximately). The number of beeps (1, 2 or 3) indicates the mode which has been set, see below.

1 beep	The button will <b>beep and flash 5 seconds</b> after being pressed (this mode allows the cancelling of accidental pressing).
2 beeps	Respond to a single press instantly by triggering an alarm and sounding a single beep.
3 beeps	Respond to a single press instantly and silently by triggering an alarm.

Choose the desired function by repeating steps 2 and 3, then reassemble the button. This configuration will not be affected by normal battery replacement (reconfiguration is only possible in the above way).

### Testing the panic button

The signals received by the control panel from the JA-187J can be checked and measured. See the control panel manual for details

### Controlling electrical appliances

The JA-187J can also be used with other Jablotron products which communicate via Jablotron radio protocol, e.g. the JA-180L wireless siren, or relay receiving modules series JA-182N and JA-180N (see the manuals of these particular products for details).

The JA-187J transmits the same kind of signal as transmitted when a pair of buttons is pressed simultaneously on an JA-186J keyfob.

The JA-187J can be enrolled to several receivers at once, e.g. alarm triggering can also cause lights to be turned on.

### Battery replacement

The button unit monitors its battery voltage and if too low, a report is sent to the control panel to inform the installer or user. A critical voltage level is also indicated by an LED flashing fast 3 times every 5 minutes. The battery should be replaced as soon as possible. As with configuration, the button can be opened by unscrewing the 4 screws from the bottom part. We recommend battery replacement be done by a service technician.

Expired batteries should not be thrown into the garbage but disposed of according to local regulations.

## Technical specifications

Voltage lithium battery type CR 2032 (3.0 V/0.2 Ah) Typical battery lifetime approx. 3 years (for 1 daily activation maximum) Communication band 868,1 MHz, Jablotron protocol Communication range approx. 50 m (open area) Environment external protected Housing -25 °C to +50 °C Operational temperature Can be operated according to ERC REC 70-03 Complies with ETSI EN 300220, EN 50130-4, EN 55022, EN 60950-1, EN 50134-2


### FCC ID VL6RC87



JABLOTRON ALARMS a.s. hereby declares that the JA-187J is in a compliance with the relevant Union harmonisation legislation: Directives No: 2014/53/EU, 2014/35/EU, 2014/30/EU, 2011/65/EU. The original of the conformity assessment can be found at www.jablotron.com - Section Downloads.



**Note**: Although this product does not contain any harmful materials we suggest you return the product to the dealer or directly to the producer after use.



The JA-187J wireless wrist button 4 MKT53003